

DT-110..

Network Type : LV

Installation tester CATEX DT-110

Application:

The CATEX testers enable you to perform the following checks:

- Presence of voltage at the terminals of a socket.
- Integrity of the earth circuit.
- Correct polarity. The position of the phase and the neutral is indicated.
- Correct operation of the RCD system at the following sensitivities : 30 mA and 500 mA.

The RCD check function is only applicable to single phase circuits: 230 V between phase and neutral.



Features:

- Operating voltage: 230 V \pm 10%.
- Frequency: 50 / 60 Hz \pm 10%.
- Operating temperature: - 15°C / + 45°C.
- IP 40 IK 03.
- Fuse protection: 2 delayed fuses 250 mA.
- CAT II 600 V

Optionnal accessories:

- Storage bag: [M-87285](#)
- [M-952271](#) : cord for intervention on LV tables.

Référence	Frequency	Weight (kg)
DT-110	50/60 Hz	0,12