

## DT-155..

Network Type : LV

### Installation tester CATEX

#### Application:

The CATEX testers enable you to perform the following checks:

- Presence of voltage at the terminals of a socket.
- Integrity of the earth circuit.
- Correct polarity. The position of the phase and the neutral is indicated.
- Correct operation of the RCD system at the following sensitivities : 10 mA, 30 mA, 300 mA, 500 mA, 650 mA.

The RCD check function is only applicable to single phase circuits: 230 V between phase and neutral.



#### Features:

- Operating voltage: 230 V  $\pm$  10%.
- Frequency: 50 / 60 Hz  $\pm$  10%.
- Operating temperature: - 15°C / + 45°C.
- IP 40 IK03.
- Fuse protection: 2 delayed fuses 250 mA
- CAT II 600 V

#### Optionnal accessories:

- **M-952271** : cord for intervention on LV tables.



Référence	Frequency	Weight (kg)
DT-155	50/60 Hz	0,16